


# MIDIPLUS




## Piano Dreams Start From Here

POP Piano intelligent piano specification



# Product Description




# Start to operate

Scan the QR code to download  
POP Piano software

Support mobile device like cellphone, pad, etc.

Support IOS 9.0 or later, Android 6.0 or later

Open your Wechat and  
scan to download APP




Press the button to start up the piano


- Red LED light indicates the piano is on for playing. Need to connect headphones, speakers or mobile APP to play the sound.
- Blinking green LED light indicates the piano is charging, battery is full when the light stays.
- Blue indicates that the piano has been successfully connected to the mobile device.

## Tips


Single click the switch button to power on, long press the button for 2 seconds to power off. The piano will power off automatically while there is no playing after 30 minutes for saving power. You can use USB port for Charging, including mobile charges, phone charges, etc.



# Use bluetooth to connect POP Piano APP




- Make sure the piano is on
- Make sure the bluetooth of cellphone or pad is on
- Find the POP Piano and connect according to the POP Piano software guidance
- Please don't connect the piano in the bluetooth of system and please operate in the POP piano.
- Indicated LED on the top left corner of piano will turn into blue from red when connect successfully.



Scan the QR code below to check on the specific ways to connect and all kinds of learning course



Place your mobile device and connect the external audio to enjoy the beauty of piano



Place your cellphone or pad in the groove which is in the middle of piano (Need to keep the network of cellphone or pad open ), you can connect the external audio device if needed, it will make the sound effect better ( the external audio device need to be prepared yourself, if there is no connecting, the sounds come from APP by default)

You could connect the pedal if needed(POP Piano has its own sustain effect, users can still learn without connecting pedal)

- Red indicator represents that need to play with left hand
- Blue indicator represents that need to play with right hand


# Learning method description

After choosing the song, follow the red&blue light on light bar to press the keys. Red light represents your left hand and blue light represents your right hand,the column bar on APP could also tell you to use right hand and left hand based on colors.

More difficult songs will be unlocked based on your proficiency.  
Please start from the songs of Level 1 .



- 1 . represents: Use thumb to play
- 2 . represents: Use index finger to play
- 3 . represents: Use middle finger to play
- 4 . represents: Use ring finger to play
- 5 . represents: Use little finger to play



|| FOR ELISE 2 / 16

5 Use little finger to play

4 Use ring finger to play

2 Use index finger to play

1 Use thumb to play






# 钢琴梦想从这里开启

POP Piano 智能钢琴使用说明书

# 产品简介






# 开始使用

扫描二维码下载 POP Piano 软件

支持手机、Pad等移动设备

支持 iOS 9.0 及以上、Android 6.0及以上版本系统

打开微信扫一扫，下载APP




## 按下开关，钢琴开启

- 红色表示钢琴已经开启，可使用，需连接耳机、音箱或手机APP才可以弹奏发声
- 绿色呼吸灯状态为正在充电，如绿灯长亮则表示电量已满
- 蓝色表示钢琴已经蓝牙连移动设备成功

## 小提示

单击开关按键开机，长按2秒关机，开机30分钟无弹奏则自动关机，以便节约电量  
本钢琴可使用USB接口充电，包括充电宝，手机充电器等



# 蓝牙连接POP Piano学习软件


确认钢琴已经打开

确认手机或者Pad的蓝牙已经打开

按照POP Piano的软件操作找到**POP Piano**钢琴并且连接

(请在POP Piano中操作，而不是在系统的蓝牙设置中连接钢琴)

连接成功时，钢琴左上角指示灯由红色变为蓝色



扫描下面二维码可以查看详情连接方法和各类教程



## 安放移动设备，连接外响，享受钢琴之美

将手机或者Pad放置到钢琴中间的凹槽(需保持设备网络畅通)

如有需要可连接外响设备，声音体验效果更佳(需自备外响，


如不连接将默认通过手机APP发声)

如有需要也可连接脚踏板(POP Piano自带延音效果，普通用户

不连接也可正常学习)

● 红色指示灯需要用左手弹奏

● 蓝色指示灯需要用右手弹奏



# 学习方法简介

选择曲目后，按照键盘灯条上红蓝灯指示按下钢琴键，红灯表示左手，蓝灯表示右手，APP上柱状条亦根据颜色区分分左右手。

曲目难度根据熟练度逐渐解锁，请从1级难度曲目开始学习。



- 1表示：用拇指弹琴
- 2表示：用食指弹琴
- 3表示：用中指弹琴
- 4表示：用无名指弹琴
- 5表示：用小指弹琴

II 致爱丽丝 2 / 16

The interface shows a piano keyboard with a green progress bar at the top. A blue bar indicates the current note being played, with a finger indicator '1' and the text '用拇指弹琴'. Other finger indicators are shown for notes further up the keyboard: '2 用食指弹琴', '4 用无名指弹琴', and '5 用小指弹琴'. A hand diagram with numbered fingers is visible on the right side of the keyboard.

[www.midiplus.com](http://www.midiplus.com)   [www.abcpiano.cn](http://www.abcpiano.cn)